

## STARTING INSTRUCTIONS

- 1) Make sure no LED lights are flashing on the [2c\temp](#) unit.
- 2) If LED is flashing this indicates unit has been already started. DO NOT USE. Place started unit aside and mark STARTED on the label.
- 3) If no LED's are flashing depress black button (use for example the tip of a paperclip) below START and make sure you see the GREEN LED flash several times. (This indicates the unit has started.)
- 4) If it does not flash repeat step 3 and make sure the button has not jammed. NOTE it should flash right after depressing the start button.
- 5) If still no flashing label as DEFECTIVE place aside and use another unit then contact Scigiene Corporation, [www.scigiene.com](http://www.scigiene.com) at 416-261-4865.
- 6) After starting and verifying operation place product immediately in the shipment and seal the box or close the container door.
- 7) If placed on a pallet or in a container datalogger should be attached in such a manner as to prevent removal for tampering and at the highest point in warm weather or lowest in cooler weather (heat rises, cold sinks).



1295 Morningside Ave Units 16, 17, & 18  
Toronto ON M1B 4Z4 Canada  
Telephone: 416-261-4865 Fax: 416-261-7879  
[www.scigiene.com](http://www.scigiene.com)