

Maxilog PDF Gen 2 Temperature USB Datalogger

USER GUIDE



Part#: MA0140

HOW TO USE

WARNING! Do not open the sleeve bag until the trip is finished and you are ready to download the report.

START THE LOGGER

Press and hold the button for at least 3 seconds till OK LED flashes 5 times. The OK LED will then flash every 2 seconds indicating the logger is working.

STOP THE LOGGER

Press and hold the button for at least 3 secs till Alarm LED flashes 5 times. Or directly plug the USB into computer to stop the logger automatically.

GET THE REPORT

Plug USB into computer. Once you plug into a computer, you might have to wait a while until the 2 LEDs become solid. Then a flash disk will pop up with the data report in the format of PDF & CSV.

SET A MARK

Double click the button, the OK LED will flash 3 times, indicating a MARK has been made successfully. A total of 10 MARKs can be made.



1295 Morningside Avenue, Unit 16-18
Scarborough, ON M1B 4Z4 Canada
Phone: 416-261-4865 Fax: 416-261-7879
www.scigiene.com

